




WIR SCHAFFEN WISSEN – HEUTE FÜR MORGEN

David Just :: Front-End Engineer :: Paul Scherrer Institute

Updated High Heat Load Front-Ends for SLS 2.0


MEDSI 2020, virtual conference presented 28.07.2021; contact: david.just@psi.ch

Purpose of a Front-End




- Delivers photon beam from storage ring to beam lines
- Securely blocks radiation to work in down stream area
- First beam conditioning
 - Beam size, diaphragm (aperture) and slits
 - Filters
- Provides feedback on photon beam position
- Sometimes it holds optical elements

Front-Ends at SLS 2.0




- All FEs required to be removed from tunnel during dark-time
- All source points and beam lines will move
- New spatial requirements due to new lattice
- We want to keep using the existing FE components where possible
 - Costs and reliability
 - modifications for safety
 - replacement of components subjected to wear
 - new apertures and slits to deal with increased power load and beam sizes
- Power load tripled
 - Most powerful undulator SLS1 = 3.3 kW, SLS 2.0 = 9.9 kW
 - Reason: 2.4 GeV → 2.7 GeV and more powerful sources

Hard X-Ray Front-End



Hard X-Ray Component Layout

- 1
- 2
- 3
- 4
- 5
- 6
- 7
- 8
- 9
- 10
- 11



1. 1st XBPM
2. Pump stand
3. Diaphragm / aperture
4. Photon shutter

5. Fast- & gate valve
6. Beam stopper
7. Slits
8. 2nd XBPM



9. Tunnel wall
10. Pump stand
11. CVD window

Hard X-Ray Front-End

- Six HXR beamlines, four IDs
 - CPMU14, 4.7 kW
 - SCU 10, 8.5 kW
 - U18, 8.8 kW
 - CPMU16, 9.9 kW
- Baseline Concept for 11 kW CPMU16 -> All HXR FEs use the same concept
- Acceptances: 94x80 μrad^2
- Status:
 - High heat load components are being engineered
 - 1st Concept for: PX-II and cSAXS

Example: Placing W-Blades

New XBPM Layout for High Power Beamlines using U10


Legend


- Used Beam
- Opening of Blades (0.26x0.42 mrad²)
- ▬ Blades
- Heat Shield
- ▬ High Power Region

$$Y = \int_{30 \text{ eV}}^{30 \text{ keV}} F'(E) \cdot BW \cdot \sigma_{ph}(E) dE$$

with: Y being the tungsten response, $F'(E)$ the flux density per Energy [ph/s/mrad²/0.1BW], BW the band width and $\sigma_{ph}(E)$ the photoelectric cross section.

Blade Thickness: 0.258 mm
Incident Angle of Blade: 26 °

New High Power Diaphragm: Model





- Defines beam-size and protects photon shutter
- Fixed positioned
- 3 in and outlet channels (\varnothing 10 mm)
- 12 cooling channels (12 mm² cross section each)
- Water flux 18 l/min
- 2 thermo couples
- Outside dimensions (HxWxL): 60x60x468 mm³
- Tapering 0.8°
- made from OFHC

New HP Diaphragm: Thermal Specs

- Distance from source: **10.6 m**
- Max power load (absorbed): 14 kW
 - U16*: 10 kW
- Max power density at distance: 693 W/mm² (effective taperd: 11.6 W/mm²)
 - U16* on axis: 539 W/mm²
- Inlet opening: 1.2x0.7mrad²
- Outlet opening: 0.094x 0.085 mrad²

*U16, 3.4 m, K=2.1, n= 189


New HP Diaphragm FEA:



	SF = 1.1 $P_{tot} = 12 \text{ kW}$	SF = 1.4 $P_{tot} = 15 \text{ kW}$	Reference Value Cu OFHC	Reference Value Glidcop
Tot. power abs. [kW]	11.2	13.9		
Max. power density [W/mm ²]	9.3	11.6	20 ⁽¹⁾ > 45 ⁽²⁾	70 ⁽¹⁾ >150 ⁽²⁾
Max. body temperature [°C]	65	80	400 ⁽⁶⁾ 541 ⁽³⁾	300 ⁽⁵⁾
Max. water temperature [°C]	29	41	150 ⁽⁴⁾	150 ⁽⁴⁾
Displacement [μm]	20	19		
Max. stress [MPa]	150	190	250..300 ⁽⁶⁾ 75 ⁽¹⁾	400 ⁽⁵⁾ 450 ⁽⁵⁾
Max. strain [%]	0.07	0.09	0.1 .. 0.5 ⁽⁶⁾ 0.2	0.2 % ⁽⁷⁾

- (1) F. Thomas et al. (ESRF): X-Ray Absorber Design and Calculations for the ESB Storage Ring, MEDSI 2016
- (2) L. Zhang et al. (ESRF): ESRF Thermal Absorbers: Temperature, Stress and Material Criteria, MEDSI 2002, For Absorber (low temperature cycling)
- (3) APS design criteria from: F. Thomas et al.: X-Ray Absorber Design and Calculations for the ESB Storage ring, Proc. of MEDSI 2016
- (4) Boiling temperature of water at 5 bar; SLS cooling water pressure = 10 bar, SLS 2.0 in discussion
- (5) APS design criteria, private communication Yifei Jaski, 450 MPa for corner stresses.
- (6) Diamond design criteria, private communication Xia Liu, using elasto-plastic strain.
- (7) Alba design criteria from: F. Thomas et al.: X-Ray Absorber Design and Calculations for the ESB Storage ring, Proc. of MEDSI 2016

Updated Hard X-Ray Photon Shutter




- Existing photon shutter can be reused
- Additional adaptions to be made (new end switches, fall through protection)
- Safety certification required (PL-R = d [potentially also e])
- New support required

Thermal

- Distance from source: 10.9 m
- Max power load (absorbed): 770 W
 - U16*: 530 W
- Max power density at distance: 723 W/mm² (effective at 3°: 40 W/mm²)
 - U16* on axis: 539 W/mm²

*U16, 3.4 m, K=2.1, n= 189

Updated Hard X-Ray Photon Shutter FEA



	SF = 1.1 $P_{\text{tot}} = 11$ kW	SF = 1.4 $P_{\text{tot}} = 15$ kW	Reference Value Cu OFHC	Reference Value Glidcop
Tot. power abs. [W]	541	771		
Max. power density [W/mm ²]	27	40	20 ⁽¹⁾ > 45 ⁽²⁾	70 ⁽¹⁾ >150 ⁽²⁾
Max. body temperature [°C]	138	191	400 ⁽⁶⁾ 541 ⁽³⁾	300 ⁽⁵⁾
Max. water temperature [°C]	48	60	150 ⁽⁴⁾	150 ⁽⁴⁾
Displacement [μm]	13	18		
Max. stress [MPa]	166	240	250..300 ⁽⁶⁾ 75 ⁽¹⁾	400 ⁽⁵⁾ 450 ⁽⁵⁾
Max. strain [%]	0.13	0.2	0.1 .. 0.5 ⁽⁶⁾ 0.2	0.2 % ⁽⁷⁾

(1) F. Thomas et al. (ESRF): X-Ray Absorber Design and Calculations for the EBS Storage Ring, MEDSI 2016

(2) L. Zhang et al. (ESRF): ESRF Thermal Absorbers: Temperature, Stress and Material Criteria, MEDSI 2002, For Absorber (low temperature cycling)

(3) APS design criteria from: F. Thomas et al.: X-Ray Absorber Design and Calculations for the ESB Storage ring, Proc. of MEDSI 2016


(4) Boiling temperature of water at 5 bar; SLS cooling water pressure = 10 bar, SLS 2.0 in discussion

(5) APS design criteria, private communication, 450 MPa for corner stresses.

(6) Diamond design criteria, private communication,

(7) Alba design criteria from: F. Thomas et al.: X-Ray Absorber Design and Calculations for the ESB Storage ring, Proc. of MEDSI 2016


Updated Beam Stopper



Beam Stopper, 30040.26.005

- In principle existing beam stopper can be reused
- Additional safety features
 - New fall through protection
 - New certified end-switches
- Bremsstrahlung coverage needs to be re-evaluated
 - Existing (180 mm) tungsten length @ 2.7 GeV

New Insertion Device Slits




New ID Slits, 30050.20.526



Des. Eng.: S. Guntli



- To be used for HXR and SXR
- Capable to fully shut the beam
- Overall length 652 mm
- Made from OFHC
- Max power: 780 W
 - U16*: 533 W
- Max power density at distance: 730 W/mm^2
(effective tapered: 8.9 W/mm^2)
 - U16* on axis: 439 W/mm^2
- Middle flanges supported to prevent parasitical motion
- Absolut encoders
- Positioning accuracy: $\sim 1 \mu\text{m}$







Beam






























Tunnel Wall Break Through



Existing tunnel wall break through
30040.36.409



New tunnel wall break through
SIM 30050.20.575



New tunnel wall break through
Debye 30050.20.521

- The existing tunnel wall break through can be reused in some cases
- New concept with casted mono block heavy concrete
 - Simulations for radiological safety planned by designated group

Wir schaffen Wissen – heute für morgen

My thanks go to

Claude Pradervand, Harald Siebold, Kevin Bühlmann,
Marcel Brüstle, Simon Guntli, Andri Bischofsberger,
Lior Day, Reto Oeschger, Brigitte Zumsteg, Alexandar
Stoyanov, Andi Keller, André Weber, Benedikt
Rösner, Christoph Schmid, Christoph Hess, Dominik
Meister, Dominique Hauenstein, Elmar Zehnder,
Gabriel Käslin, Ilaria Besana, Johan Wickström, Jonas
Buchmann, Juri Honegger, Lothar Schultz, Nazareno
Gaiffi, Peter Wiegand, Peter Huber, Philip Willmott,
Reto Widmer, Romain Ganter, Rüdiger Scheibl,
Thomas Schmidt, Uli Frommherz, Uwe Flechsig and
the BL staff

